

HSM Wire International, Inc.

Phone: 330-244-8501 Fax: 330-244-8561

www.hsmwire.com

Weight Conversion Factors

Methods of Calculating the Weight of Wire Cloth

Weight conversion factors

To find the approximate weight of wire cloth, multiply the weight of stainless steel as listed in the wire cloth tables by the appropriate factor listed below.

Aluminum (EC0 and 1100)	339
Aluminum (5056)	328
Brass, cartridge (70/30)	1.065
Brass, low (80/20)	1.083
Bronze, comm. (90/10)	1.010
Bronze, phosphor (A)	1.107
Carpenter® 20CB3	1.010
Copper	1.114
Gold	2.415
Haynes® 25 (L605)	1.142
Hastelloy® B	1.155
Hastelloy® C	1.117
Hoskins 502	1.993
Inconel® 600	1.052
Incoloy® 800994
Molybdenum	1.277
Monel® 400	1.103
Nichrome®	1.031
Nichrome® I	1.010
Nichrome® V	1.052
Nickel 200	1.110
Platinum	2.681
Silver	1.311
Stainless steel (302, 304, 316, 347)	1.000
Stainless steel (410, 430)990
Steel (1008)985
Steel (1042)980
Tantalum	2.072
Titanium561
Tungsten	2.401

NOTE: The following registered trademarks are recognized – Hastelloy and Haynes: Haynes International, Inc.; Inconel and Monel: the Inco family of companies; Nichrome: Driver-Harris Co.

Calculating Clear Opening, Wire Diameter, Center-to-Center Distance, and Open Area Percentage

M = Mesh count (number of wires per lineal inch)

D = Wire diameter

C = Center to center distance, wire to wire

A = Clear opening between wires

$$C = \frac{1}{M} A = C - D$$

$$\text{Open Area Percent} = (M \times A)^2 \times 100$$

Example: 4 Mesh/.063" Dia. Wire

$$C = \frac{1}{4} = .250"$$

$$A = .250" - .063 = .187"$$

$$\text{Open Area Percent} = (4 \times .187)^2 \times 100 = 56\%$$

Metric Users

Because 'mesh count' has a direct functional relationship to 1 inch, use the conversion tables provided on our website to convert all metric measurements to inches before using the equations above to perform calculations. The equations above are formulated for metric calculations.

$$\text{Opening [mm]} = (25.4/\text{mesh count}) - \text{wire diameter [mm]}$$

$$\text{Mesh Count} = 25.4/(\text{opening [mm]} + \text{wire diameter [mm]})$$

$$\text{Open Area Percent} = \frac{\text{opening [mm]}^2}{(\text{opening [mm]} + \text{wire diameter [mm]})^2} \times 160$$

Area : To convert inches² to mm², multiply inches² x 6.4516

To convert feet² to m², multiply feet² x 9.290304